



Accessories for S7-Panel-HMIs

There are available pin marked removable connectors either with lift arms or with bolt flanges to connect INSEVIS devices. This allows an explicit positioning of each pin to the signals and makes the wiring easier. The wire-contact is done by maintenance free cage-clamps for max. 1,5mm² cross sections without wire end sleeves.

A mounting set with grounding terminal is part of every delivery.

Figure of accessories	Accessories	Article-no.	MOQ (pcs)
<p>Connectors</p>  <p>E-CON16* E-CONS16 (pin marked connectors for max. 1,5mm² cross sections)</p>	<p>For devices with CPU V/P:</p> <p>Connector 2x8pin, lift arms* * → discontinued, to be replaced by</p> <p>Connector 2x8pin, bolt flanges (mechanically compatible replacement)</p> <p>Adapter for Profibus SUB-D9</p>	<p>E-CON16-00*</p> <p>E-CONS16-00</p> <p>E-AD-DP12-00</p>	<p>1</p> <p>1</p> <p>1</p>
 <p>E-CON10* E-CONS10 (pin marked connectors for max. 1,5mm² cross sections)</p>	<p>For devices with CPU T:</p> <p>Connector 2x5pin, lift arms* * → discontinued, to be replaced by</p> <p>Connector 2x5pin, bolt flanges (mechanically compatible replacement)</p>	<p>E-CON10-00*</p> <p>E-CONS10-00</p>	<p>1</p> <p>1</p>
<p>External memory</p>  <p>Hint: S7-program runs without these cards, these parts are used for archiving / recipes / updating only</p>	<p>Micro SD-card 1GB (external memory)</p> <p>Micro SD-card 2GB (external memory)</p> <p>Micro SD-card 4GB (external memory)</p> <p>Micro SD-card 8GB (external memory)</p>	<p>E-MSD1-00</p> <p>E-MSD2-00</p> <p>E-MSD4-00</p> <p>E-MSD8-00</p>	<p>1</p> <p>1</p> <p>1</p> <p>1</p>
<p>Customized labeling</p> <p>Hint: ¹⁾ Single fix costs only, no run-time costs per single HMI</p>	<p>OEM- firmware with integrated customer logo</p> <p>Inserting stripes H with customer logo (rear)</p>	<p>SW-BS-OEM ¹⁾</p> <p>E-LABH-00</p>	<p>1</p> <p>100</p>
<p>Software</p> <p>Hint: ²⁾ Company license, no run-time costs per single PC ³⁾ Maintenance license due yearly, if new versions are required, otherwise only old versions do run Software for free download at INSEVIS web sites</p>	<p>VisuStage</p> <p>ConfigStage</p> <p>RemoteStage</p> <p>ServiceStage</p> <p>VisuStage full version company license</p> <p>VisuStage full version maintenance lic.</p>	<p>-</p> <p>-</p> <p>-</p> <p>-</p> <p>SW-VS-2.0 ²⁾</p> <p>SW-VSW-2.0 ²⁾³⁾</p>	<p>free download</p> <p>free download</p> <p>free download</p> <p>free download</p> <p>1</p> <p>1</p>
<p>Spare parts</p> <p>Hint: A mounting set with grounding terminal is part of every delivery</p>	<p>Additional mounting set with grounding terminal for 3,5" and 4,3"-devices</p> <p>Additional mounting set with grounding terminal for 5,7" and 7"-devices</p> <p>Additional mounting set with grounding terminal for 10,1"-devices</p> <p>Additional mounting set with grounding terminal for 15,6"-devices</p>	<p>E-MNT35-00</p> <p>E-MNT57-00</p> <p>E-MNT101-00</p> <p>E-MNT156-00</p>	<p>10</p> <p>10</p> <p>10</p> <p>10</p>
<p>Part of every delivery</p>	<p>mounting set with grounding terminal</p> <p>technical data sheet</p>	<p>none</p>	<p>-</p>

Stainless steel front plates, attached parts and customized designs on request.